


### Adjusting Rings Rondanas de Ajuste Baagues d'arrêt

A2
A4



<b>d<sub>1</sub></b>	<b>5</b>	<b>6</b>	<b>8</b>	<b>9</b>	<b>10</b>	<b>11</b>	<b>12</b>	<b>13</b>	<b>14</b>	<b>15</b>	<b>16</b>
b	6	8	8	10	10	10	12	12	12	12	12
d <sub>2</sub>	10	12	16	18	20	20	22	22	25	25	28
d <sub>3</sub>	M3	M4	M4	M5	M5	M5	M6	M6	M6	M6	M6
W	.280	.548	.940	1.44	1.85	1.74	2.52	2.32	3.17	2.98	3.84

<b>d<sub>1</sub></b>	<b>18</b>	<b>20</b>	<b>22</b>	<b>24</b>	<b>25</b>	<b>26</b>	<b>28</b>	<b>30</b>	<b>32</b>	<b>34</b>	<b>35</b>
b	14	14	14	16	16	16	16	16	16	16	16
d <sub>2</sub>	32	32	36	40	40	40	45	45	50	50	56
d <sub>3</sub>	M6	M6	M6	M8	M8	M8	M8	M8	M8	M8	M8
W	6.0	5.3	6.9	10.0	9.56	9.05	12.2	11.1	14.5	13.4	18.7

<b>d<sub>1</sub></b>	<b>36</b>	<b>40</b>	<b>45</b>	<b>50</b>
b	16	18	18	18
d <sub>2</sub>	56	63	70	80
d <sub>3</sub>	M8	M10	M10	M10
W	18	26.1	31.7	42.9

(W ~ Weights of standard sizes in kilograms per 1000 pieces)